

Installation guide

**Pressure transmitters**


DST P40I / DST P 40M

078R0003

078R0003



Forbundet til kapsling  
Connected to enclosure  
Mit Gehäuse verbunden  
Liaison au boîtier



Forsyningsspænding [ $U_s$ ]:  
Supply voltage [ $U_s$ ]:  
Versorgungsspannung [ $U_s$ ]:  
Tension d'alimentation [ $U_s$ ]:

9 – 32 V

Bemærk | Note | Achtung | Attention

